Introduction

Thank you very much for purchasing our product!

The heater description will provide you with detailed information about the heater's construction, technical specifications and operation. We recommend that you read this information carefully. This will help you avoid potential errors during your own installation and operation.

Detailed installation and operating conditions can be found in the General Operating Instructions (included in the delivery).

Notes in the text

EN



The most important notes are those labeled WARNING. Notes labeled WARNING alert you to **serious risk of damage to the heater or injury.**



The note labeled Warning warns you of possible damage to your heater.



A note labeled Important alerts you to information important for the operation of your heater.



As such, the note draws your attention to information that is important for the operation of your heater in general.

Machine translation – not reviewed.
Unchanged original at the end.


Contents

1. Dimensional diagram..... 1
2. Spare parts list 2
2.1. Overall model breakdown 2
2.2. Detail A1..... 4
3. Easy control 5

Machine translation – not reviewed.
Unchanged original at the end.

2. Spare parts list

2.1. Exploded view of the model




Position	Name	Amount	Item number
Exploded view of the model			
A1	Firebox door (set)/black	1 pc	0470815105300
B1	Hinge fasteners (set)	2 pcs	0088016006635
1	Ash pan	1 pc	0432215005600
2	Barrier/black	1 pc	0470815005050
3	Grate/black	1 pc	0429415005005
4	Fireclay 30x45x260	1 pc	0470815005181
5	Fireclay 30x105x200	2 pcs	0470815005161

Machine translation – not reviewed.
Unchanged original at the end.

6	Fireclay 30x202x290	1 pc	0470815005152
7	Fireclay 30x202x290	1 pc	0470815005151
8	Fireclay 30x160x267	2 pcs	0470815005191
9	Lower diaphragm	1 pc	0470215005002
10	Aperture holder	1 pc	0470815005018
11	Upper diaphragm	1 pc	0470215015104
12a	Easycontrol controller	1 pc	0470815005402
12b	Handle regulator	1 pc	0430815005322
13	Top lid/black	1 pc	0470815005800
14	Rear cover	1 pc	0470815005805
15	Spring-loaded tile holder	2 pcs	0088400010005
16	Ceramic side cladding	2 pcs	0470815005130

Machine translation – not reviewed.
Unchanged original at the end.

2.2. Detail A1



Position	Name	Amount	Item number
Detail A1			
A1.1.	Handle material connection	1 pc	0470815005301
A1.2.	Glass holder — set/black	1 pc	0416515015304
17a	Handle pull/black	1 pc	0470815105305
17b	Handle handle	1 pc	0430815005321
18	Firebox door/black	1 pc	0470815005200
19	Door sealing cord 12 mm	2150 mm	0040012120005
20	Glass sealing cord 10x4 mm	1460 mm	0040210040005
21	Heat-resistant glass (4x285x445)	1 pc	0470615005301

Machine translation – not reviewed.
Unchanged original at the end.

3. Easy control


Control of all three air inlets (primary, secondary, tertiary) using only one regulator.


1. The regulator is in the ignition position (Fig. A). All three air inlets (primary, secondary, tertiary).
2. Setting the Easy control regulator in heating mode (fig. B). 3. The regulator is in the position

   intended for closing the air inlets (fig. C). No inlet is open
   (primary, secondary, tertiary). This position is only used when the stove is out of operation, after the heating process has ended.

WARNING

During the heating process, the air inlets must not be closed (Fig. C)! In extreme cases, an explosion in the stove may occur, resulting in glass shattering, embers scattering around the room and a fire.





Machine translation – not reviewed.
Unchanged original at the end.

HAAS + SOHN

Foresta

Technická dokumentace
Krbová kamna

CZ

04708151014000c

Úvod

Srdečně děkujeme za zakoupení našeho výrobku!

Popis topidla Vás podrobně seznámí s konstrukcí, technickou specifikací a obsluhou topidla. Doporučujeme seznámit se pozorně s těmito údaji. Vyvarujete se tak případných chyb při vlastní montáži a obsluze.

Podrobné podmínky instalace a obsluhy naleznete ve Všeobecném návodu k obsluze (součást dodávky).

Poznámky v textu



Nejdůležitější jsou poznámky nadepsané **VAROVÁNÍ**. Poznámky nadepsané **VAROVÁNÍ** Vás upozorňují na **vážné nebezpečí poškození topidla či poranění.**



Poznámka nadepsaná **Upozornění** Vás upozorňuje na možná poškození Vašeho topidla.



Poznámka nadepsaná **Důležité** Vás upozorňuje na informace důležité k provozu Vašeho topidla.



Poznámka jako taková Vás upozorňuje zcela obecně na informace důležité k provozu Vašeho topidla.

CZ


Obsah

1. Rozměrové schéma 1

2. Seznam náhradních dílů 2
2.1. Celkový rozstřel modelu 2
2.2. Detail A1 4


3. Easy control 5

1. Rozměrové schéma



2. Seznam náhradních dílů


2.1. Celkový rozstřel modelu



Pozice	Název	Množství	Číslo zboží
Celkový rozstřel modelu			
A1	Dvířka topeniště (komplet)/černá	1 ks	0470815105300
B1	Spojovací materiál pantu (komplet)	2 ks	0088016006635
1	Popelník	1 ks	0432215005600
2	Zábrana/černá	1 ks	0470815005050
3	Rošt/černá	1 ks	0429415005005
4	Šamot 30x45x260	1 ks	0470815005181
5	Šamot 30x105x200	2 ks	0470815005161

6	Šamot 30x202x290	1 ks	0470815005152
7	Šamot 30x202x290	1 ks	0470815005151
8	Šamot 30x160x267	2 ks	0470815005191
9	Clona spodní	1 ks	0470215005002
10	Držák clony	1 ks	0470815005018
11	Clona horní	1 ks	0470215015104
12a	Regulátor Easycontrol	1 ks	0470815005402
12b	Madlo regulátor	1 ks	0430815005322
13	Vrchní víko/černá	1 ks	0470815005800
14	Zadní kryt	1 ks	0470815005805
15	Pružinový držák obkladu	2 ks	0088400010005
16	Keramický obklad boční	2 ks	0470815005130

2.2. Detail A1



Pozice	Název	Množství	Číslo zboží
Detail A1			
A1.1.	Spoj. mat. kliky	1 ks	0470815005301
A1.2.	Držák skla — set/černá	1 ks	0416515015304
17a	Táhlo kliky/černá	1 ks	0470815105305
17b	Madlo kliky	1 ks	0430815005321
18	Dvířka topeniště/černá	1 ks	0470815005200
19	Těsnící šňůra dveří 12 mm	2150 mm	0040012120005
20	Těsnící šňůra skla 10x4 mm	1460 mm	0040210040005
21	Žáruvzdorné sklo (4x285x445)	1 ks	0470615005301

3. Easy control

Ovládání všech tří přívodů vzduchů (primárního, sekundárního, terciárního) pouze pomocí jednoho regulátoru.

1. Regulátor je v pozici určené pro zátop (obr. A). Jsou otevřeny všechny tři přívody vzduchu (primární, sekundární, terciární).
2. Nastavení regulátoru Easy control v režimu topení (obr. B).
3. Regulátor je v pozici určené pro uzavření přívodů vzduchu (obr. C). Žádný přívod není otevřen (primární, sekundární, terciární). Tato pozice se používá pouze v případě, kdy jsou kamna mimo provoz, po ukončení procesu topení.

VAROVÁNÍ

Během procesu topení nesmí dojít k uzavření přívodů vzduchu (obr. C)! V krajním případě může dojít i k explozi v kamnech a následnému roztříštění skla, rozmetání uhlíků po místnosti a ke vzniku požáru.

